

UNIVERSAL FOR ONE BRAND

Use for PHILIPS SERIES: TV/LCD/LED/HDTV

3D **LCD** **LED** **SMART TV** **LEARN**

MODEL: PH-12/13/19/20+L

Thanks for choosing this remote control. Please install the batteries and try. If it works well, no need to set. If it does not work, please refer to the following setting method. This remote control could save the setting when changing batteries.


★ Before use this remote control, please read this manual as much as possible.

It could directly control 98% models of PHILIPS brand, no need to set. If it doesn't work please choose one of the following setting ways to use.


A. INPUT CODE

CODE LIST:	001.002.003.004.005.006
	007.008.009.010.011

- 1). Press and hold the key [MUTE] and [POWER], after 3 seconds the LED will be lit.



- 2). Release the keys, input the three codes from code list. When the codes input finished, the LED will turn off.



- 3). Please try to use the remote control. If it doesn't work well, please try other codes: [002]、[003]、[004] ...

NOTE: If the three codes are invalid, the LED will flash twice and keep light, if the codes are right, LED light will turn off.

If you want to exit set , please press [MUTE] key.

B. FAST SEARCH

- 1). Press and hold the key [⏻] and [MUTE], after 3 seconds the LED will be lit, release keys.

- 2). Press the key [CH+], each time you press it will search once. When the channel changes, you can test [⏻], [VOL+], [MENU], [0~9] keys work well, if ok ,please press [MUTE] key to save and exit.
- 3). If it doesn't work well , please repeat from Step.2

C. CODE INQUIRY

To know what codes the remote control is using:

- 1). Press and hold the key [MUTE] firstly, then press [⏻] key, after 3 seconds LED will light, release keys.
- 2). Input [9].[9].[0] with number keys. LED will flash twice and be off.
- 3). Press [1]/[2]/[3]. For example : Pressing [1], LED will start to flash. The flashes times is the code's first number. If code number is [0]. LED will not flash.

D. Learning Function


- 1). Press and hold the key [MUTE] firstly, then long press [+] about 5 seconds, the LED will be lit. Release the two keys. It is ready to learn.



- 2). Point the original remote control to PH-19/20. The distance should be within 3-5cm.



- 3). Press any key of the original remote control, the indicator on PH-19/20 remote control will flash after receive information, release it. Then press the key on PH-19/20 remote control, indicator light flashes twice and keep. Please repeat Step.3 to continue learning other function keys.



- 4). After learning all the keys, please press and hold the key [MUTE] firstly, then press [-], the LED will be off. The learning will be saved.



NOTE: During the learning process, if no key is pressed in 25 seconds the learning state will be exited without saving.

E. Compatible Remote Control Model

Due to too many Remote Control models, we only list some below. If your remote control is similar to the picture, then our remote can control it.

