

RM-L1662

Characteristics



Thank you for using our company remote control product, Please try it after installing batteries at first time, if all functions are normal, you can use directly without setting. If it can't work normal, you need to make the following setting, then you can use for your TV.

Turn on your TV set, and aim the remote to the TV, select the code. Press "POWER" key, then press "corresponding digital" key, setting to be finished, and test the function.

Compatible Types List

List some suitable types of remote control according to relevant materials, for your guidance.



558W52
ESS1XD



ACONATIC
43HS521AN



ALHAFIDH
06-558W52-TY19XS



COMPAQ 06-558
W52-TY06XS



HAIER



LCD 06-
558W52-TY12XS



LCD 06-558
W52-TY18XS



LCD TV REMOTE
06-558W52-TY08XD



LCD TV REMOTE
with EYESAFE

POWER+0 POWER+0 POWER+0 POWER+0



LCD WT
925-05



LCD WT
925-07



LCD 06-552
W52-TY02X-



SINGER 06-518
W31TY03DA

POWER+1

POWER+1

POWER+1

POWER+1



KALLEY 06-
558W52-TY18XS



LCD 06-558
W52-TY11XS



LCD HG
20190510



TOPHOUSE
06-558W52-TY05XS

POWER+2

POWER+2

POWER+3

POWER+4



CONDOR
CSR722-TN3



TORNADO
WT-0L96



X-VISION 06
558W52-XV01XS



GO SAT 06-558
W52-GST1XD

POWER+5

POWER+6

POWER+6

POWER+7



IRIS OHYAMA
LT-ARCS



LCD TV REMOTE
with EYESAFE



LCD WT925-07



HITACHI CLE-1032

Beli elektronik
www.belielektronik.rs