

# SUITABLE FOR THE BELOW SAMSUNG



## Function description:

This product is SAMSUNG universal remote control. It can be used directly for most SAMSUNG models.

In case it can't be used for your TV directly, please press the button POWER and 1 Return to the factory settings, press the button POWER and 0

# SUITABLE FOR THE BELOW SAMSUNG



# SAMSUNG MODELS:

# NG MODELS:

