

EV015.0 280-868MHz Universal Remote Control Duplicator

Multi frequency rolling code remote Control duplicator user manual

Features:
 1 for all
 Multi-frequency & auto scan
 Easy duplicating
 Patent right reserved
 Duplicating procedures:



Programming

FIXED CODE DUPLICATING PROCEDURES

- 1) While pressing the button 1, press 4 times the button 2.
- 2) Release both buttons. Now the led of the EV015.0 emits a quick flash every 2 sec.
- 3) Place the original remote control in front of the "EV015.0", at about 4-60 cm of distance (as shown in the picture above).
- 4) Press and retain pressed the button of the original remote control that you want to copy until the EV015.0's LED will change frequency of flashing (faster than before), as a confirmation of the correct copy of the code.
- 5) While the LED is flashing, press the button of the "EV015.0" where you want to store the code just copied, until the led turns off.
- 6) The copy has been applied with success. Verify on the automation the orderly functioning of the new remote control.

ROLLING DUPLICATING PROCEDURES

- 1) While pressing the button 1 of the "EV015.0", press 4 times the button 2. Release both buttons. Now the LED of the WHY emits a quick flash every 2 sec.
- 2) Place the original remote control in front of the "EV015.0", at about 4-60 cm of distance.
- 3) Press and retain pressed the button of the original remote control that you want to copy until the EV015.0's led will turn on with a light and then emits a double flash every 2 sec.
- 3) Transmit now the seed code of the original remote control (by pressing the rear hide button or the buttons 1 and 2 simultaneously in the new models)
- 4) Now the LED will fish quickly, press the button of the "EV015.0" where you want to store the code just copied, until the LED will turn off.
- 5) Now activate the procedure to insert the new remote control on the receiver.

BFT

1. While pressing the button 1 of the "EV015.0", at the same time press 4 times the 2 button.
2. Release both buttons. Now the EV015.0 LED will emit a short flash every 2 seconds.
3. Place the original remote control to be programmed in front of the "EV015.0", at about 4-60 cm of distance.
4. Press and retain pressed the button to be programmed of the original remote control, till the LED will switch on as a fix light; now release the button.
5. The EV015.0 LED will emit a short flash every 2 seconds
6. Transmit now the SEED CODE of the BFT original remote control, press the hidden buttons until the original remote control LED switches on.
7. Now the EV015.0 LED will change the flash mode (more fast), for a reconfirmation of the correct code learning. This step may take some seconds.
8. At this moment, press the new remote button when you want to store the code and retain pressed until the EV015.0 LED switches off
9. Activate now the procedure to insert the new remote control on the receiver.

Compatible List

Brand	Model	Brand	Model
ACM (AMC)	TX2, TX2 COLOR, TX4	KEY	900TXB-42R, SUB44, TXB-44R, TXG-44R
ADYX	TE443SH BLUE, 433-HG BRAVO	KINGGATES	STYLQ, CLIPPER
AERF	COMPACT, HY-DOM, MERCURI B, MERCURI C, SABUTON, MARS, SATURN, ST3/N, TERRA, TMP-1, TMP-2, UNITECH	KLING	KUA, KUAE, KUA S
ALLIMATIC (AMC)	BROWN, BROWN RED, BRO, OVER, PASS, MINIFASS, TECH3, FOR4	LABEL	SPYCO, R/W4E
APERIO	GO, GO PRO, GO MINI	LEB	TMW
APERTO (SOMMER)	TX02-434-2, TX02-868-2 BLUE, 4025 TX02-868-2, 4022 TX02-434-2, 4020 TX03-434, TX03-868-4, 4013, TX03-434-4	LINCE	LR2035
APRIMATIC (AMC)	TR2/TR4, TM4, TXM	LIFE	LIFE FID2 / FID04 / VIP2 / VIP4 / VIP2R / VIP4R / STAR2 / STAR4 / BRAVO2 / BRAVO4
ATA	PTX4 BLUUM PTX4 PINK	LINEAR	MCT-11, ACT-22, ACT-21, STRING RAY ACT-31, STRING RAY ACT-34B
AVIDSEN	104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250, TX4 114253	MHOUSE (AMC)	GTX4, GTX4C, TX4
		MA	TX1, TX2, TX3
		MOOVO (AMC)	MT4G

BALLAN	FM400, FM400E, FM404B, 4013	MARANTEC	D101,D12,DIGITAL302,DIGITAL304
BENINCA (AMC)	TO.GO.WW, TWV, ROLLKEY, APPLE, LOT.WCV, CUPIDO, TO.GO.QV, IO, LOT2.WCV, LOT1W, LOT2W, LOT4W, LOT1WM, LOT2WM, T2W, T4W, HAPPY VA, IO, TO.GO.VA	MERLIN+ /Gifco MERLIN 2.0	M230T/PROLIFT, M430T/PROLIFT, C945, C940, C943, CM842, CM844 E945M,E943M, E940M
BESIDE	BEZAP, HIT	MONSIEUR	ARC
BFT (AMC)	MITTO, MITTO M(MITTO 2M/MITTO4M), MITTO RCB/MITTO RCB02/MITTO RCB04), MITTO(MITTO 2A/MITTO 4A), MITTO B, TRC(TRC2/TRC4), GHIBLI, MURALE, KLO, TEO1, TEO2, TE04, R84 MURALE	NORMSTHAL NICE	RCU 2/4 K, EA433 2/4 K SMILO, FLOR-5, VERY-VR, FLOR-5 ERA, ONE (ON), ON ERA, INTI, ERGO, PLANO, ONE (ON FM)
CAME	T431, T434, TOP432A, TOP434a, TOP432, TAM432SA, TOP432NA	NORTON	NEO, TXCD, GO NORTON, GO MINI NORTON
CARDIN (AMC)	TRQ.S449, TRQ.S449 GREEN (PRECODE), TXQ.S449, TXQ.S449 GREEN, TRQ.S486, TXQ.S486, S437 TX, KRADO	NOVOTECHNICA (AMC)	BLXL2 MCBS, MICRO-NOVOTRON 502, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS, MINI NOVOTRON 522
CASALI	JA33 AMIGO, GENIUS/CASALI A252RC	NOVOFERM	
CASIT	ERTS92B, ERTS92T, ERTS476D, ERTS20DQ, ERTS476D, ERTS476Q	NOLOGO	ECO DIP
CELISA	S10 1, S10 2	O&O (AMC)	TX, T.BOM, TWIN,TX, TWIN,TX2/TX4, TX(NEO)
CENTURION	CLASSIC, SMART	O&G	OG62, OG64
CHAMBERLIN/ LIFTMASTER/ MOTORLIFT	953ESTD, 371 LM, 971LM, 84330E, 94334CE94333E/94334E/94335E, 9747E, 1A5639-7.1A5477.1A6-487, 13282372, 94330EM-L/9333EML/94335EML, 84330EML/84331EM-L/84335EML, 8747EML	OPENBOUT PECCININ PORTAMATIC	TMQ TX MENBRANA MPH01, MPH02
CLEMSA	MUTANCODE, T, T-B, E-CODE N, MASTERCODE MV	PRASTEL	MTE, MPSTLE, MPSTP2E, TCE, BFOR, TRQ-P, SLIM-E
CPS	TCP3, CPS1, CPS2, CPS4	PRODEM	ER4AC4CS
DASPI (AMC)	HAPPY2, POPS 2, ZERO RC(ZERO 2RC, 4RC)	PROGET	ETY_433N2, ETY_433N4
DEA	PUNTO 278, GOLD, GENIE R 273, GENIE R-GT2M, MIO TR, GT2M, TRN	PROTECO	TX433, EUROMATIC
DELMA	MIXARD 433 1, MIXARD 433 2, KING 433 2	PUJOL	TWIN, VARIO, VARIO MARS, VARIO OCEAN, NED
DICKERT	MAH5433 01, MAH5433 04	QUASAR	433
DITEC/ENTREOMATIC (AMC)	GOL, GOL4C, BIXL52, BIXLP2, BIXLG4, BIXLG, ZEN	RIB	LITHILO
DOORMATIC	SAW, MILENY, MILENY-EVO	ROPER	NEO, GO ROPER, GO MINI ROPER
DOITRANO	MPSTF2E, JAUNE	SABUTOM	BROOVER, BROSTAR
DOORHAN	TRANSMITTER 4	SEA	HEAD, SMART DUAL ROLL, SMART-3 ROLLING CODE, COCCOMELLA ROLL
DUCATI	TS4W1, TS4W2, TS4W3, 124, TE2	SECULUX	NEO
ECOSTAR	RSE, RSC, RSZ	SEAV	BE HAPPY RS(BE-HAPPY-RS1,BE-HAPPY-RS2,BE-HAPPY-RS3), BE-SMART RSX, BE-HAPPY RH1, BE-HAPPY RH2, BE-HAPPY RH3, BE SMART
ELBE	S01, 502, 504, 502A, 504A		
ERREKA	IRIS, ROLLER 2, ROLLER 433, ROLLER 868, SOL433, SOL868, VEGA 433, VEGA 868	SILVELOX	MHZ2007, QUARZ SAW
ELCA	IRIS, ASTER, ASTER 1000, ASTER 1001	SICE	4790207
FAAC (AMC)	XT433 RC, TM1 433 DS, TM2 433 DS, TM3 433 DS, 433L2, 433L4, TM2 433 SLP, TM4 433 SLP, TLM 433SLH, TLM 868SLH, DL 868SHL, XT 868SHL, XT 433SHL, T 868SHL, T 433SHL, T433HRC, T433HG	SIMINOR SEUCURVERA	CVXNL, MITTO, SIM433 SV R2C, SV R4C, SV R6C
FADINI (AMC)	FADINI JUBI, JUBI SMALL, ASTRO 4.3 SMALL, 433 M2 ASTRO 433-2, ASTRO 433-4, JUBI2/JUBI4, JUBI 433, DIVO 71/4	SERAI	06/52, OG54, OG62, OG84, OG/28, OG48, OG62, OG64
FERPORT	TAC1, TAC2, TAC4, TAC 1K, TAC 2K, TAC 4K, TAC2KR	SOMFY	LE95, K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA
GBIDI	GBIDI OPEN/TMB, OPEN/OUT, AU01590, AU1600, DOM0- NO AU1680 WOOD, GBIDI AU1610, GBIDI AU1680, AU1810, AU03000/AU03000 DOMINO/DTC, 4334, DT54334-AU0400, MAKO	SOMMER	SOMMER 4026 TX03-868-2, SOMMER 4020 TX03-868-4, SOMMER 4031, SOMMER 4025, SOMMER 4011, SOMMER 4095, APERTO 4025
GULLIVER	MDW	STAGNOLI	KALLISTO, VENUS AV/23
GENIUS (AMC)	AMIGO, AMIGOLD, KILO, BRAVO, ECHO	TAU (AMC)	250K-SLIMRP, 250K-SLIMR, 250T-4RP
GENIE (AMC)	GITR-3, GIT, GICT390, GIT390-1, G3T-BX, G1T-BX, GM3T, GICTD, GIFTD	TELCOMA	FM402, FM402E, FM400E, FM400
HORMANN	HSM2, HSM4	TORLIFT	TORMIT4
JCM	NEO, TWIN, GO, GO PORTIS, GO NORTON, GO MINI	VDS (AMC)	TRQ_P, ECO-R
JAY	UBBX 1SL1, UBET 21, U8ET 41, UBET 61	VARWFORD	EA433 4K, SMART2, SMART3
KBLUE	ETH-TEL01	V2 (AMC)	V2 PHOX 2, V2 PHOX 4,V2 PHOENIX 2,V2 PHOENIX 4,V2 TXC,V2 TRC,V2 TSC4,V2 HAND, PHOX 868, PHOX 868