

USER MANUAL

☒ 433.92Mhz ☐ 315Mhz ☐ 868.3Mhz

Product Description

The duplicator remote control will provide you some backup remotes via clone original remote. It is widely used in home alarms, panic buttons, garage door, rolling curtain, etc.

The chips compatibility:

2260(All the manufacturers)
2262(All the manufacturers)
PT2264/2240/5326(All the manufacturers)

SC5262, HT/600/6P20B/680/
6207/6010/6012/6014, SMC918
Series, 527(All the manufacturers)


1527(All the manufacturers)
2240(All the manufacturers)

Single chip of fixed code

.....

All fixed code

Learning way:



Please refer to *Figure (I)* to confirm the ABCD key on duplicator remote control.

1. Erase the code


- Press button A and B Simultaneously until LED flashes.
- Release button B and keep pressing button A, then press button B 3 times, LED flash fast indicate succeed to clean code(release both button now)



2. Duplicating


- Put **Duplicator** aside of **Original** transmitter as close as possible.
- Press and hold button A of **Duplicator**, LED flash 3 times fast.

Then press and hold button A of **Original** transmitter, duplicator LED flash 3 times slowly and keep lighting.



- Release both buttons, finish code copy. Duplicate other keys in same way.

(Note: please back to back like *figure (IV)* to duplicate again, if the key duplicated in *figure (III)* doesn't work effectively.



3. Resume

Press and hold button C and D simultaneously until the LED flashes, all buttons return back to the latest duplicated codes.